

Soundbox Setup Guide



Image 1



Image 2

SIM Card Mode

1. Open the cover on the bottom of the device. (Refer to Image 1)
2. Insert the SIM card into the card slot at the bottom. (Refer to Image 2)
3. Long press the power button for 3 seconds, until the device power on.
4. When the screen displays or voice prompts ‘Connecting...’, you can start to set up the network.
5. Press the ‘+’ and ‘-’ button together to change language.
6. Long press the ‘+’ button for 3 seconds, and the device will switch the communication mode.
7. When the voice prompts ‘SIM Card Mode’, it means the device is working with SIM Card now.
8. The device will automatically connect to the cloud server.
9. When you see the welcome screen or see the status LED flashing a green light, it means the device is connected

WiFi Mode

1. Long press the power button for 3 seconds, until the device power on.
2. When the screen displays or voice prompts ‘Connecting...’, you can start to set up the network.
3. Press the ‘+’ and ‘-’ button together to change language.
4. Long press the ‘+’ button for 3 seconds, and the device will switch the communication mode.
5. When the voice prompts ‘WiFi Mode’, it means the device is working with WiFi now.
6. Long press the ‘-’ button for 3 seconds.
7. When the voice prompts ‘Please set wireless parameters’, the device is in WiFi config mode
8. The device will generate a WiFi hotspot named ‘NEXGO-XXXXX’, ‘XXXXX’ is the last 5 digits of the device serial number.
9. Use mobile phone or PC to connect to hotspot. Then, open the browser and visit 192.168.1.1
10. Choose the target WiFi and enter the password, then click ‘Submit’
11. Device will broadcast ‘Configuration Success’
12. The device will automatically connect to the cloud server.
13. When you see the welcome screen or see the status LED flashing a green light, it means the device is connected



For any questions please contact

+60146329133
soundboxcare@alpcapital.my



Panduan Persediaan Soundbox



Imej 1



Imej 2

Mod Kad SIM

1. Buka penutup di bahagian bawah peranti. (Rujuk Imej 1)
2. Masukkan kad SIM ke dalam slot kad di bahagian bawah. (Rujuk Imej 2)
3. Tekan lama butang kuasa selama 3 saat sehingga peranti dihidupkan.
4. Apabila skrin memaparkan atau bersuara ‘Connecting...’, anda boleh mula menyediakan rangkaian.
5. Tekan butang ‘+’ dan ‘-’ bersama-sama untuk menukar bahasa.
6. Tekan lama butang ‘+’ selama 3 saat dan peranti akan menukar mod komunikasi.
7. Apabila peranti anda bersuara ‘Mod Kad SIM’, ini bermakna peranti sedang berfungsi dengan Kad SIM sekarang.
8. Peranti akan bersambung secara automatik ke pelayan awan *(cloud server)*.
9. Apabila anda melihat skrin menyala atau status LED berkelip lampu hijau, ini bermakna peranti disambungkan.

Mod WiFi

1. Tekan lama butang kuasa selama 3 saat sehingga peranti dihidupkan.
2. Apabila skrin memaparkan atau bersuara ‘Connecting...’, anda boleh mula menyediakan rangkaian.
3. Tekan butang ‘+’ dan ‘-’ bersama-sama untuk menukar bahasa.
4. Tekan lama butang ‘+’ selama 3 saat dan peranti akan menukar mod komunikasi.
5. Apabila peranti anda bersuara ‘Mod WiFi’, ini bermakna peranti sedang berfungsi dengan WiFi sekarang.
6. Tekan lama butang ‘-’ selama 3 saat.
7. Apabila peranti bersuara ‘Sila tetapkan wireless parameter anda’, peranti berada dalam mod konfigurasi WiFi.
8. Peranti akan menjana tempat liputan WiFi bernama 'NEXGO-XXXXX', 'XXXXX' ialah 5 digit terakhir nombor siri peranti.
9. Gunakan telefon bimbit atau PC untuk menyambung ke tempat liputan. Kemudian, buka pelayar internet dan lawati 192.168.1.1
10. Pilih WiFi sasaran dan masukkan kata laluan, kemudian klik 'Submit'
11. Peranti akan menyiarkan ‘Konfigurasi Berjaya’.
12. Peranti akan bersambung secara automatik ke pelayan awan *(cloud server)*.
13. Apabila anda melihat skrin menyala atau status LED berkelip lampu hijau, ini bermakna peranti disambungkan.



Sebarang pertanyaan sila hubungi

+60146329133
soundboxcare@alpcapital.my